


**SPECIFICATIONS**  
**DIMENSIONS**  
(Unit: mm, not to scale)



| Lead & Terminal NO | Function                  | Lead & Terminal NO | Function     |
|--------------------|---------------------------|--------------------|--------------|
| ①                  | Vcc1(PLL IC)              | ⑦                  | RF Output    |
| ②                  | GND                       | ⑧                  | GND          |
| ③                  | Reference Frequency Input | ⑨                  | Lock Detect  |
| ④                  | GND                       | ⑩                  | Clock Input  |
| ⑤                  | Vcc2(VCO)                 | ⑪                  | Data Input   |
| ⑥                  | GND                       | ⑫                  | Enable Input |

**CALL OUR SALES DEPARTMENT FOR MORE INFORMATION OR VARIATIONS OF THIS PRODUCT.**

**Corry Micronics, Inc. One Plastics Rd. - Corry, PA 16407**  
**(814) 664-7728 Fax (814) 664-4582 [www.cormic.com](http://www.cormic.com)**

Corry Micronics Inc. herein referred to CMI, believes this information to be accurate, but makes no warranties, expressed or implied as to the accuracy of this document. CMI assumes no liability for any injury, loss, damage, direct or consequential arising from the use of our products. User assumes all risk whatsoever in connection with it's intended use. CMI also reserves the right to change this document without notice.